Small Label UID Format for Part Tracking



Presented BY
APTEC International, Inc.
Robert Rylander and Associates

Agenda

- What is UID
- Data, Application Text Identifiers
- UID Structure
- UID Training
- Small Label Marking
 - Benefits
 - Specifications
 - Applications
- Live Demonstration

- UID provides the ability to distinguish one item from another.
- UID is Globally Unique
- Data integrity throughout the life of an Item
- Data Quality

- Set of Data Elements for tangible assets
 - Enterprise Identifier, Serial Number
 - Enterprise Identifier, Part Number, Serial Number
- Assigned by an Enterprise
 - Business organization or firm
 - Commercial partnership (two or more persons)
- Enterprise Identifier
 - Assigned by registration or controlling authority
 - Dun & Bradstreet's (DUNS)
 - Uniform Code Council (UCC) / International (EAN)
 - Defense Logistics Information Service (CAGE)

- Two Methods (Construct #1 and #2)
- Serialization within the Enterprise Identifier
 - Issuing agency code
 - Enterprise Identifier
 - Unique Serial Number (numbers / letters)
 - Assigned by the manufacturer / vendor


- 2. Serialization within a Part Number
 - Issuing agency code
 - Enterprise Identifier
 - Original Part Number (numbers / letters)
 - Same form, fit, function, and interface
 - Unique Serial Number (numbers / letters)
 - Assigned by the manufacturer / vendor

- Acceptable Alternatives
- Must meet data requirements for unique identification
 - EAN.UCC Global Individual Asset Identifier (GIAI)
 - EAN.UCC Returnable Asset Identifier (GRIA)
 - ISO Vehicle Identification Number (VIN)
 - Electronic Serial Number (ESN) for cellular phones only
 - EPC Electronic Product Code
 - For further understanding go too:

http://www.acq.osd.mil/uid

A DI is defined as a specified character (or string of characters) that defines the general category or specified use of the data that follows.

- P
- 1P
- 12P
- \123P



Sample Categories (6 of 27)

D = Date

H= Human resources

K= Trading Partner Transaction

L= Location

P= Item

Q= Measurement

Category 16

P = Item ID (customer assigned)

1P = Item ID (supplier assigned)

2P = Rev Level, Eng. Change

30P = Current Part Number

20P-24P= Extension of P

30P-34P = Extension of IP

... Plus Others

Category 22 (Party to the Transaction)

12V= DUNS number identifying the manufacturer

17V= U.S. DOD CAGE Number

Category 19 Traceability number for an entry

- S = Serial Number assigned by supplier
- 25S = Unique Identifier Including Issuing agency code
- 18S = Unique Identifier not Including Issuing agency code

Application Identifiers Content Al **Format** Serial Shipping Container Code 00 N2 + N18Shipping Container Code 01 N2 + N14Quantity Each N2 + N...830 Ship to (deliver to) postal code 420 N3+AN...9Ship to postal code with 3-digit ISO N3+N3+AN...9 421

... Plus Others


- Text Elements
 - Air Line Industry
 - Spec 2000 Data Directory
 - CAGE CAG * MFR / SPL***
 - DUNs
 DUN *
 - EAN.UCC EUC *
 - SN within EID SER / UCN**
 - SN within PN SEQ *
 - Original PN PNO *
 - Current PN PNR
 - * = Cannot be used in UID Construct 2
 - ** = Enterprise other then Manufacturer
 - Text Elements are three characters.

Data, Application, Text DI / Al and Text Elements Equivalent

Enterprise ID	DI	A]	Text Elements
Cage/NCAGE	17V		CAG * MFR/SPL
DUNS	12V		DUN*
EAN. UCC	3V		EUC*
Other Agencies	18V	95	
SN within EID			SER/UCN
SN within PN	S	21	SEQ*
Original PN	1P	01	PNO*
Current PN	30P	240	PNR
UID with IAC	255	8004	
UID no IAC	185		USN/UST

^{*} Cannot be used until approved by Air Transport Association





MILSTD 130L Format

Issuing Agency Codes (IACs)

Issuing Agency	Issuing Agency	Enterprise ID
Code		
0-9	EAN-International EAN.UC	CC
LB	Telcordia Technologies	ANSI T1.220
UN	Dun & Bradstreet	DUNS
D	Allied Committee 135	CAGE
LH	European Health Industry	y EHIBCC
	Business Communication	ıs
	Council	

- Creating and Generating a UID
 - Only the Enterprise Identifier that assigned the SN can be used in the UID
 - Other data elements must be discrete (data qualifier) and be placed last in a mark
 - UID Data Elements shall be contained in:
 - Data Matrix ECC200 symbol
 - Contact memory buttons
 - 1D bar codes
 - InfoDot (preprinted labels)
 - RFID
 - Marks must remain legible for the life of the Item
 - If space available Human Readable UID information should be marked on the item.

- Metadata Requirements
 - UID not to exceed 78 characters
 - IAC not to exceed 3 characters
 - Enterprise Identifier not to exceed 13 characters *
 - Original Part Number not to exceed 32 characters
 - Serial Number not to exceed 30 characters *
 - Possible 78 UID characters but the use of shorter field lengths is encouraged.
 - * = Excluding Data Qualifiers

- Metadata Requirements
 - UID string of data must have worldwide uniqueness
 - Spaces should be deleted from UID data
 - No special characters in the El
 - Only dashes (-) and forward slash (/) all other special characters are deleted from PN and SN
 - UID must contain upper case A-Z 0-9 and (-) (/)

- Special Rules for Existing Inventory
 - Enterprise Identifier missing
 - Use Activity for the EI
 - Part Number missing
 - Obtain PN from in-service engineer
 - Serial Number missing
 - Assign SN locally along with Activity as El
 - Material Unidentifiable
 - UID should not be used
 - Program Manager could use Lot / Batch as a prefix to the serial number (munitions)

- Structuring Data Elements for Uniqueness
 - Data Identifiers (ISO/IEC 15434 Format 06)
 - Application Identifiers (ISO/IEC 15434 Format 05)
 - Text Element Identifiers (ISO/IEC TS 21849)

Data Identifiers Format 06

Data Elemen	ts DI	Data Value	Encoded Data
EI DUNS	12V	077991289	12V 077991289
SN with IAC	25S	UN077991289	255 UN077991289
		674A36458	674A36458
SN within PN	S	10936	5 10936
Original PN	1P	4202435	1P4202435
Current PN	30P	4202435-01	30P4202435-01
UID no IAC	185	0CVA5674A3	185 0CVA5674A3

Construct #1

 $[)>_{R_S}06_{G_S}$ 255UN077991289674A36458 $_{R_S}$ EO_T Reader Output: UN077991289674A36458

[)>R_S06G_S**185**0CVA5674A36458R_SEO_T Reader Output: **D0CVA5674A36458**

Construct # 2

 $[)>_{R_S}06_{G_S}$ 12V077991289 $_{G_S}$ 1P4202435 $_{G_S}$ 510936 $_{R_S}$ EoT Reader Output: UN077991289420243510936

Application Identifier Format 05

Data Elements	Al	Data Value	Encoded Data
Other Agencies	95	12345	9512345
SN within EID8004	061414	11A0B9C3D6 <mark>8004</mark> 0	06141411A0B9C3D6
SN within PN	21	1A0B9C3D6	21 1A0B9C3D6
Original PN	01	00061414199999	01 00061414199999
Current PN	240	4202435-01	2404202435-01

Construct #1

 $[)>_{R_S}05_{G_S}800406141411A0B9C3D6_{S}EO_{T}$

Reader Output:06141411A0B9C3D6

Construct #2

 $[)>R_S05G_S$ 0100061414199999 G_S 211A0B9C3D6 R_SEO_T

Reader Output:0006141419999991A0B9C3D6

Data Elements	TEIs	Data Value	Encoded Data
CAGE	MFR	0CVA5	MFR0CVA5
SN within EID	SER	674A36458	SER674A36458
CAGE (EID not MFG)	SPL	0F3N5	SPL0F3N5
SN (EDI not MFG)	UCN	10936	UCN10936
Current PN	PNR	4202435-01	PNR 4202435-01

Construct #1

[)>R_SDDG_SMFR0CVA5G_SSER674A36458R_SEO_T Reader Output:D0CVA5674A36458

[)>R_SDDG_SSPL0F3N5G_SUCN10936R_SEO_T Reader Output: D0F3N510936

- 1. TEIs = 3 Alpha characters
- DD = Special, interim DOD specified format header
- Cannot use construct #2 until CAG, SEQ, PNO, have been approved by Air Transport Association.

http://www.acq.osd.mil/uid

```
Data Identifiers
             Add IAC for Cage (D) for complete UID
   185
             Constructed UID Has IAC
   25S
      17V (cage)/12V (Duns) UID= IAC+17V/12V+1P+S
      18V (Other Agencies) UID=18V+1P+S
             Constructed UID Equivalent (VIN) ISO: Vehicle ID
             Constructed UID Equivalent (ESN) Electronic SN
   225
             Constructed UID Equivalent (GIAI/GRAI)
   1B
             UCC/EAN: Global Individual Asset ID / Global Returnable Asset ID
             Constructed UID Equivalent (GRIA)
   5B
      UCC/EAN: Global Returnable Individual Asset ID
```

Application Identifiers

```
21 UID=01+21 (01=14 characters)
```

```
8004 Constructed UID Equivalent (GIAI)
```

8003 Constructed UID Equivalent (GRAI)

8002 Constructed UID Equivalent (ESN)

Text Elements


```
SER UID=IAC+MFR+SER (cage code)
```

USN/UST Add IAC for cage (D) for

Complete UID (Universal SN / Universal Serial Tracking #)

UID Training

- Seminars
- Webinar
- Self Paced Training CDs
 - www.infodotllc.com
 - Free less shipping and handling \$50
 - Upon Registration
 - UID Updates Provided for 1 year



Small Label Marking (InfoDot)

Benefits

- Radial form factor provides for the most data in the smallest area
- Non obtrusive small radial format
- Orientation not critical
- Is human & machine readable
- Easy to field apply
- Provides an audit trail for entered items



Small Label Marking (InfoDot)

- Specifications
 - Size
 - ¼" Data Amount Construct #1 Up to 40 Chars
 - 3/8" Data Amount Construct #2 Up to 50 Chars
 - Larger radial InfoDots available as a custom size
 - Material
 - Standard: .003" Flexible and Durable Acrylate
 - Foil: .003" Flexible Anodized Aluminum
 - Up to 700f
 - UV Exposure / Salt Air & Water / Caustics

Small Label Marking (InfoDot)

- Specifications
 - Testing Agencies
 - Independent lab test (APTECH)
 - Sterility testing
 - Bio Compatibility
 - Metalcraft R/D testing

Metalcraft Test Results


Environmental, Chemical Atmosphere & Contact Tests Continued...

Product Tested	Test Conditions	Effect on Readability
Image Intensified	Heptane, 72 hours	No effect
Photo Anodized	 Hydrocarbon fluid 	No effect
	• JP-4 fuel	No effect
	Kerosene	No effect
	 Methyl Ethyl Ketone 	No effect
	 Nitric Acid, 1% 40 hours 	No effect
	 Phosphoric Acid, 1% 40 hours 	No effect
	Skydrol	No effect
	 Sodium Hydroxide 	Affects overall readability
	Sulfuric Acid, 10% 24 hours	No effect
	 Turbine and jet fuel (Mil-L 5161C) 	No effect
	 Tetra sodium pryo- phosphate, 1% 40 hours 	No effect
	Trisodium Phosphate	No effect

- Surgical Instrument Tracking
 - Old Methods
 - Problems
 - Surgical tape limitations
 - Manual Process
 - Prone to error
 - Time consuming
 - Lost or stolen
 - CJD Incidence
 - Incomplete trays
 - 30% tray error




- Surgical Instrument Tracking
 - New Methods
 - Labeling
 - User applied
 - Surface prep
 - Scan and associate data description
 - Instrument Trays
 - Unique label
 - Tray fulfillment
 - Autoclave Process
 - Load records provide sterilization data
 - Surgical Procedure



- Surgical Instrument Tracking
 - Scanning Instruments
 - Benefits
 - Delivers "Mission Critical" Instruments to the war fighter
 - To identify items associated with subassemblies
 - Navy
 - 9 Hospital Facilities including 2 Hospital Ships





- Tool Tracking
 - Old Methods
 - Problems
 - Laser Etch
 - Expensive
 - Logistics
 - Scribe Tools
 - Hard to read
 - Lost Tools
 - Non traceable
 - Replacement cost
 - Non availability



- Tool Tracking
 - New Methods
 - Labeling Tools
 - Check in / Check Out
 - Configuration Control
 - Benefits:











- Home Land Security
- Evidence Tracking
 - Old Method
 - Problems
 - Lost Evidence
 - Transcribing Errors
 - New Method
 - Label Evidence
 - Scan InfoDot
 - Pictures
 - Voice Recording
 - GPS





- Asset Management
 - Old Method
 - Problems
 - Large Labels
 - Esthetics
 - Durability
 - Direct Part Marking Limitations



- Asset Management
 - New Method
 - UID Labeling at the Activity
 - Construct #1 Activity / SN
 - User Defined blocks of Labels
 - Label Asset
 - Scan InfoDot
 - Enter Data into PDA
 - Locations GPS / Tag
 - Inventories
 - Check In /Check Out
 - Transfer Assets
 - Asset Lookup / History
 - Field Maintenance
 - Live Demonstration





Thank You

Questions?